




Dimension

A


6

JV Axial piston pump


JV15A*RX / A*RX-*RC / SA**RX



JV15A*R / A*R-*RC / SA**R




JV15C**RHX / C**RJ*X




Dimension


JV15C**RHX / C**RJ*X



JV23A*RX / A*RX-*RC / SA**RX



JV23 A※R / A※R-*RC / SA※※R






Dimension

A


8

JV Axial piston pump


JV23 C※※RHX / C※※RJ※X



JV23 D※※R※X




JV23 D※※R※X




Dimension


JV38A*RX / A*RX-*RC / SA**RX



JV38A*R / A*R-*RC / SA**R



JV38 C**RHX / C**RJ*X






Dimension

A


10

JV/Axial piston pump

JV38 D**R*X



JV70A*RX / A*RX-*RC / SA**RX



JV70 C※※RHX

